







Defi Sports Display F <DF15903> マニュアル

Defi Sports Display F <DF15903> をご購入いただき誠にありがとうございます。
 本マニュアルの記載内容は、DF15903 の「DF15901 との相違点」のみです。
 記載内容以外につきましては、DF15901 の取扱説明書をあわせてご確認ください
 だけますようお願いいたします。

【DF15901 との相違点】

- ・パネルデザイン
- ・タッチパネル非搭載
- ・OBDII ハーネス / ハーネスアダプター非同梱（別売）
- ・メーターハーネス 2m 付属

構成部品につきましては、以下のリストをご確認ください。

 DSD F 本体 1 ケ	 DSD F 用スイッチ 1 ケ	 電源ハーネス 1 ケ
 メーターハーネス 1 ケ	 GNSS アンテナ 1 ケ	 両面テープ 1 ケ
 タイラップ 5 ケ	 取付金 2 ケ	 M4 取付ボルト・ ワッシャー・ナット・ スプリングワッシャー 各 4 ケ
 スイッチ取付用 4×12 タッピングネジ 2 ケ 取付台 1 ケ	 エレクトロタップ 4 ケ	 ピタック 1 ケ





Defi Sports Display F <DF15903> Manual

Thank you for purchasing Defi Sports Display F <DF15903>
 The contents of this manual are only "Differences from DF15901" of DF15903.
 For items other than those described, please also refer to the manual of
 DF15901.

[Differences from DF15901]

- Panel design
- No touch panel
- OBDII wire / adapter wire not included (sold separately)
- Meter wire 2m (6 3/5ft) included

Check the list below for components.

 DSD F main unit 1pc	 Switch unit for DSD F 1pc	 Power source wire 1pc
 Meter wire 1pc	 GNSS antenna 1pc	 Double sided tape 1pc
 Plastic band 5pcs	 Mounting bracket 2pcs	 M4 bolt · washer · nut · spring washer 4pcs each
 4×12 tapping screw 2pcs Mounting bracket 1pc for switch mounting	 Solderless connector 4pcs	 Clip 1pc